



Part No. 8198666

# CABINET PARTS

For Models: ET1MTKXKQ03, ET1MTKXKT03  
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT2225762	Service & Wiring Sheet
	LIT2225944	Energy Label
	LIT2225411	Use & Care Guide
	LIT2225413	Customer Instructions

## Following May Be Purchased

### DO-IT-YOURSELF REPAIR MANUALS

	LIT677969	Do-It-Yourself Manual, Ref./Fzr.
2	2189410	Hinge (Top)
3	2166108	Roller, Front (2)
4	489464	Screw, 8-18 x 1/2
5	489385	Clamp, Tube (Water Supply Line)
9	489341	Washer
10	2179826	Rivet
11	3400504	Screw
12	549193	Clamp, Cord
15	489497	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	8281265	Screw (7)
20	2189194	Hinge Butt
23	2172743	Shim, Bottom Hinge
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2201012	White
	2200924	Biscuit
28		Seal, Front (Not Serviced)
30		Seal, Rear (Not Serviced)
35		Corner Filler (2)
	2201014	White
	2200926	Biscuit
36		Grille
	2254313	White
	2254316	Biscuit
37	2189356	Clip, Grille
38	487576	Washer
40		Cover, Hinge
	2213360	White
	2213364	Biscuit
41		Rail, Center (Not Serviced)
44	2202884	Cover, Unit
45		Cabinet (Not a Serviceable Part)


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: ET1MTKXKQ03, ET1MTKXKT03

(White)

(Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: ET1MTKXKQ03, ET1MTKXKT03  
(White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #9 & #22)
	2183915	White
	2205282	Biscuit
5		Handle Center
	2202807W	White
	2202807T	Biscuit
6	489357	Screw
8	8281146	Screw
9	2202875	Door Gasket, Magnetic
11	2201061	Trim, Door Shelf
12		Cover, Screw
	2202819W	White
	2202819T	Biscuit
13	2255121	Nameplate
14	2195943	Trim, Door Shelf
16	2195378	Trim, Door Shelf
17	8281206	Screw
18	2201062	Trim, Door
19		Freezer Door (Includes #22 & #23)
	2182489	White
	2204686	Biscuit
20		Hole Plug
	2189000	White
	2200936	Biscuit
21	2188236	Shelf, Flip-Up
22	2183003	Thimble
23	2214967	Door Gasket, Magnetic
24	2156003	Endcap, Trim (4)
25	2195915	Endcap, Trim (2)
26	2189202	Bracket, Door Stop (2)
27	488921	Screw
28		Hole Plug
	2212648	White
	2212649	Biscuit
29	2156007	Plug, Trim
30	2156006	Plug, Trim
31	2218118	Compartment Door
33		Handle, F.C.
	2202806W	White
	2202806T	Biscuit
37	2201060	Trim, Door (2)
41	2156003	Endcap, Trim (4)
42	2195948	Trim, Door

# LINER PARTS

For Models: ET1MTKXKQ03, ET1MTKXKT03

(White)

(Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LINER PARTS


For Models: ET1MTKXKQ03, ET1MTKXKT03  
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not a Serviceable Part)
2	2197380	Grommet (2)
3	2254360	Gasket, Evaporator Cover (2)
4	2188376	Defrost Timer
5	2204640	Thermostat, Tube Barrier
6	941839	Hole Plug
7	2221668	Wire Assembly Control Box
8	2162085	Socket, Light (2)
9	98129	Screw (2)
10	2214986	Fan Motor
11	2163777	Fan Blade
12	2218381	Control Box
13	2204605	Thermostat Assy. (Includes Item 5)
14	489478	Screw
16	2254263	Cover, Evaporator
17	2160708	Light Bulb
18	2214976	Bracket Evap. Fan, Rear
19	1118894	Switch, Rocker Arm
21	2176281	Cover, Air Diffuser
22	2202885	Knob, Thermostat
23	2254354	Air Tower
24	2189452	Air Diffuser, Bottom
25	2221677	Defrost, BI-Metal
26	2204690	Air Diffuser, Top
27	2205003	Cover, Hole
28	2210509	Valve-Tube, Body
29	2218696	Bracket, Fan Motor
30	2214979	Bracket Evap. Fan, Front
31	2204639	Shield, Heat
32	487996	Cap
33	2187690	Wire Assembly Freezer Compartment
34	940014	Hole Plug, Control Box

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Models: ET1MTKXKQ03, ET1MTKXKT03  
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Models: ET1MTKXKQ03, ET1MTKXKT03  
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2225596	Plate, Unit Mounting
3	2214960	Condenser
4	2166124	Heater, Defrost
5	2254249	Evaporator Assy.
6	489494	Screw
7	2254295	Drain Pan
9	2176301	Bracket, Heater
10	2163780	Extension, Air Baffle
11	2255113	Strap
12	4387731	Cover (Service Only)
13	4387766	Overload (Service Only) (Includes Relay)
14		Grommet (4)
	1100826	Production
	4387558	Service
15	2225785	Start-Device Combination (Start Relay and Overload for Production Compressor Only)

Illus. No.	Part No.	DESCRIPTION
16	489478	Screw
17	2150304	Roller (2)
18	2221797	Rivet
19	2182338	Clip, Heater
20	489373	Screw
21		Nut (Not Serviced)
23	2201185	Support Block
24	3400518	Screw
25	531933	Grommet
28	2225833	Compressor (Includes Items 12,13,14,29 & 32)
29		Drier
	2199167	Production
	4387019	Service
30	2155774	Clamp
32		Capacitor
	2169373	Production
	4387764	Service
39	2198921	Air Baffle
40	2206005	Motor, Condenser
41	2210750	Plate
42	2187382	Wire Assy, Unit
43	2190685	Fan Blade
44	486692	Nut
46	2225564	Tube, Discharge
47	2225565	Tube, Suction
48	2212848	Tube, Process
56	488500	Screw
58	2225517	Tray, Evaporator

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

## REFRIGERANT CHARGE

4.00 Ozs.  
(R134A)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# SHELF PARTS

For Models: ET1MTKXKQ03, ET1MTKXKT03  
(White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	2210522	Shelf, Ladder (2)
2	2202821	Shelf, Ladder Center
3	2174693	Glass, Full Shelf
4	2163762	Cup, Shelf Mtg.
5	489478	Screw
6	2188687	Trim Shelf, Rear
7	2201102E	Shelf, Cantilever
8	2188685	Trim, Shelf Front
9	2210524	Crisper Cover
10	2188691C	Trim Shelf, Front
11	2210573	Insert, Crisper Cover
12	2201106	Pan Shelf, Cantilever
14	2200987	Glass, Shelf
15	2163832	Crisper Support
16	2201104	Shelf, Full Cantilever
17	2189454	Shelf, Freezer
18	2188689C	Trim, Shelf Rear
19	2188711	Trim Shelf, Side
20	2218132K	Pan, Meat
21	2216624	Egg Bin
22	841180	Ice Tray (2)
24	2218124	Crisper Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: ET1MTKXKQ03, ET1MTKXKT03  
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b>Parts Not Illustrated and Optional Parts (Not Included)</b>			<b>Customer Touch-Up Material</b>			<b>Refinishing Material</b>		
	978941	Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")		*350942	Primer, White (12 Oz. Spray Can)		799340	Enamel, Black (1 Qt. Uncut)
	212643	Sealer, Gum (4 Feet)		*350939	Enamel, Black (12 Oz. Spray Can)		799344	Enamel, White (1 Qt. Uncut)
	479502	Tape, Vinyl (3/4" x 108")		*350930	Enamel, White (12 Oz. Spray Can)		4392900	Enamel, Biscuit (1 Qt. Uncut)
	876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")		*4392901	Enamel, Biscuit (12 Oz. Spray Can)		833938	Kit, Terminal Connector
	876370	Kit, Insulation (2 Pcs. 3" x 24" x 48")		72017	Brush Touch-Up Kit (White)		<b>*Important:</b> The spray paint is not to be used where the paint may make contact with the door gaskets.	
	876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")		72032	Brush Touch-Up Kit (Black)			
	505587	Sealer, Mastic (1 Qt.)		4392899	Brush Touch-Up Kit (Biscuit)		<b>ICE MAKER FIELD INSTALLABLE</b>	
	511873	Touch-Up, White Porcelain (2 Oz.)					2155469	ECKMF94
	542638	Grease, Silicone (1/2 Oz.)					<b>TORX SCREW WRENCH</b>	
	542639	Cement, Alumilastic (1-1/4 Oz.)					1117510	Torx Key
	606755	Bag, Insulation (36-5/8" x 46")						
	799833	Kit, Evaporator Repair (Aluminum Epoxy)						
	799832	Kit, Porcelain Repair (White)						
	503695	Cork Sealer (1/4 Pound)						